How to Calibrate an IMU

How do I configure my IMU values?

openINS Sensor Transformation Configuration File

The configuration file that handles the sensor transformations is named openins_xforms.yml. To edit the IMU attitude bias values you will need to edit the imu_sensor: section.

```
<Put IMU cal 1 here>
```

The following conventions are used in the configuration file:

```
phi_offset = Roll Offset
theta_offset = Pitch Offset
psi_offset = Heading Offset
```

Note: It is important to maintain the same spacing in the configuration file. An added space or invalid character will result in errors during the openINS startup.

Article ID: 63

Source URL: http://localhost:8888/kb2017/how-calibrate-imu