

Alarm Channel Descriptions

Published on Greensea Knowledge Base (<http://localhost:8888/kb2017>)

Alarm Channel Descriptions

Alarm Field Name	Description
ID object	An auto generated field by process client.
Input	The command channel for the input
Transform	The condition for the alarm, less than, equals greater than
Priority	The alarm priority is set with the toggle arrows in advanced view.
Severity	The severity of the alarm ranges from informational to fatal.
Message	An optional message to display with alarm
Action	External actions viewable from the advanced view tab. An example is a command line action, or audible alarm.
Note	A field to hold any special notes for the alarm

Category: [Workflow - Alarms](#) [1]

Applies to: [Balefire Basic](#) [2]

Article ID: 142

Source URL: <http://localhost:8888/kb2017/alarm-channel-descriptions>

Links

[1] <http://localhost:8888/kb2017/main-categories/workflow-alarms>

[2] <http://localhost:8888/kb2017/applies/balefire-basic>