

Compass Data

The Compass section of the [Vehicle Sensors](#) [1] screen displays the following information:

Field	Description
Timestamp	The Unix timestamp of the most current compass reading.
Heading	The current vehicle heading in degrees.
Pitch	The vehicle pitch, or rotation about the vehicle's y-axis.
Roll	The vehicle roll, or rotation about the vehicle's x-axis.

Category: [Workspace - Diagnostics](#) [2]

Applies to: [Balefire Basic](#) [3]

Source URL: <http://localhost:8888/kb2017/compass-data>

Links

[1] <https://greenseainc.com/kb/vehicle-sensors-0>

[2] <http://localhost:8888/kb2017/main-categories/workspace-diagnostics>

[3] <http://localhost:8888/kb2017/applies/balefire-basic>