

## Device Diagnostics



The Device Diagnostics, accessed by clicking the stethoscope icon, page allows the operator to monitor navigational and operational data in real time. The Device Diagnostics page groups data by both device and function so that operators have an effective tool for easily understanding the health and status of the vehicle and vehicle subsystems. The Device Diagnostics page features two tabs: [Vehicle Sensors](#) [1] and [Vehicle Configuration](#) [2].

**Category:** [Workspace - Diagnostics](#) [3]

**Applies to:** [Balefire Basic](#) [4]

**Article ID:** 27

**Source URL:** <http://localhost:8888/kb2017/device-diagnostics>

### Links

[1] <https://greenseainc.com/kb/vehicle-sensors-0>

[2] <https://greenseainc.com/kb/vehicle-configuration>

[3] <http://localhost:8888/kb2017/main-categories/workspace-diagnostics>

[4] <http://localhost:8888/kb2017/applies/balefire-basic>