

Locating Your Vehicle

"Where is my vehicle?"

You may have moved to an area on the map with a magnified perspective that does not have your vehicle in view. Clicking the **Center On** button will fix this.

The **Center On** button keeps the vehicle in view. If the vehicle moves off the visible screen area, clicking the **Center On** button will focus the map view on the vehicle. It will remain centered around the vehicle until the button is clicked again.

Category: [Workspace - Flight View](#) [1]

Applies to: [Balefire Basic](#) [2]

[Mission View](#) [3]

Article ID: 158

Source URL: <http://localhost:8888/kb2017/locating-your-vehicle>

Links

[1] <http://localhost:8888/kb2017/main-categories/workspace-flight-view>

[2] <http://localhost:8888/kb2017/applies/balefire-basic>

[3] <http://localhost:8888/kb2017/applies/mission-view>