

Mean Altitude

Published on Greensea Knowledge Base (<http://localhost:8888/kb2017>)

Mean Altitude

Your mean [altitude](#) [1] is your average recorded [altitude](#) [1]. [Altitude](#) [1] is measured in distance above sea level. This default measurement is in meters. If you prefer, go to the defaults menu and change the measurements to imperial. This will make your [altitude](#) [1] as well as the rest of the measured in feet rather than meters.

Source URL: <http://localhost:8888/kb2017/mean-altitude-0>

Links

[1] <http://greenseainc.com/kb/lexicon/1#altitude>

[2] <http://greenseainc.com/kb/lexicon/1#ui>