

Mission Tab

The mission configuration tab provides functions for saving, recalling, and managing missions.

WaypointsChartsMarkersMan Over BoardLoggingPlaybackMissionPosition / DeclinationDebug

Active Mission:

Load Mission From File

Save Missions in

Browse

File prefix

Clear Mission From Map

Save Mission

Push Mission To Vehicle

Pull Mission From Vehicle

Button/Field	Description
Load Mission File	Allows user to load a mission file.
Clear Mission From Map	Clears current mission from the map.
Push Mission to Vehicle	Pushes a mission to the vehicle.
Pull Mission From Vehicle	Pulls an existing mission from the vehicle.
Save Mission	Saves the mission in the specified folder.
Save Mission in	Specifies the mission save location.
Browse	Allows the operator to browse the computer to specify a save location.
File Prefix	Allows the operator to specify the file prefix.

The Mission Planning folder contains several articles that take the topic to greater depth.

Category: [Workflow - Mission Planning & Executing](#) [1]
Applies to: [Balefire Basic](#) [2]
[Mission View](#) [3]
Article ID: 31

Source URL: <http://localhost:8888/kb2017/mission-tab>

- Links**
[1] <http://localhost:8888/kb2017/main-categories/workflow-mission-planning-executing>
[2] <http://localhost:8888/kb2017/applies/balefire-basic>
[3] <http://localhost:8888/kb2017/applies/mission-view>