Pressure Data

The Pressure section of the <u>Vehicle Sensors</u> [1] screen displays the following information:

Field	Description
Timestamp	The Unix timestamp of the most current pressure reading.
Count	The count of pressure readings received.
Pressure	The current pressure reading.

Category: <u>Workspace - Diagnostics</u> [2] Applies to: <u>Balefire Basic</u> [3] Article ID: 139

Source URL: http://localhost:8888/kb2017/pressure-data

Links

[1] https://greenseainc.com/kb/vehicle-sensors-0

[2] http://localhost:8888/kb2017/main-categories/workspace-diagnostics

[3] http://localhost:8888/kb2017/applies/balefire-basic