

## Resize the Workspace Views

The workspace is designed to provide operators task-specific views so that the data and functions required for the particular task can be most prominent and accessible. The components of the workspace are all completely resizable. Separation bars divide the workspace components into functional groups. When the workspace component separation bars are hovered over, they change to yellow and a double-arrow cursor appears. Click and drag the separator to the desired size. The components can be sized to zero to make more room for components of particular operator interest.

**Article ID:** 43

**Source URL:** <http://localhost:8888/kb2017/resize-workspace-views>