


Specifying Waypoint Mission Order

"How do I start my mission at a specific waypoint?"

There are a couple of ways to select an active waypoint. The first is to right-click on the waypoint and click GoTo position. The second is by changing the order in the waypoint menu. Click the row of the desired waypoint and drag it to the desired order of go. The waypoint on the top of the column is the first target waypoint.



Category: [Workflow - Mission Planning & Executing](#) [1]

Applies to: [Balefire Basic](#) [2]

[Mission View](#) [3]

Article ID: 165

Source URL: <http://localhost:8888/kb2017/specifying-waypoint-mission-order>

Links

[1] <http://localhost:8888/kb2017/main-categories/workflow-mission-planning-executing>

[2] <http://localhost:8888/kb2017/applies/balefire-basic>

[3] <http://localhost:8888/kb2017/applies/mission-view>