

Waypoint Includes Z

Published on Greensea Knowledge Base (<http://localhost:8888/kb2017>)

Waypoint Includes Z

During the waypoint route execution, the vehicle will try to achieve each waypoint until the waypoint tolerance is met. Selecting "Waypoint Includes Z" enforces the vertical component of the waypoint is met before considering the waypoint achieved. If this is not selected, the vehicle will consider the waypoint met if only the X and Y positions are met.

Category: [Workflow - Mission Planning & Executing](#) [1]

Applies to: [Balefire Basic](#) [2]

[Mission View](#) [3]

Article ID: 177

Source URL: <http://localhost:8888/kb2017/waypoint-includes-z>

Links

[1] <http://localhost:8888/kb2017/main-categories/workflow-mission-planning-executing>

[2] <http://localhost:8888/kb2017/applies/balefire-basic>

[3] <http://localhost:8888/kb2017/applies/mission-view>