





**Most Popular Topics** 



# **Copyright Notice**

This material is copyright protected. No material may be reproduced or transmitted in any form or by any means for any purpose without expressed written consent of VideoRay LLC.

Copyright © 2019, VideoRay LLC - The Global Leader in Micro-ROV Technology

# **Language Support**



Powered by Google™Translate

B.67	Arabic	Table of Contents	Internet connection required, results not guaranteed
*7	Chinese	Table of Contents	Internet connection required, results not guaranteed
	Deutsch	Table of Contents	Internet-Verbindung erforderlich, ergebnisse nicht garantiert
100 FE	English	Table of Contents	
S.	Espanol	Tabla de contenidos	Requiere conexion a Internet, los resultados no garantizados
	Francaise	<u>Table des matieres</u>	Connexion Internet requise, resultats non garantis
	Italiano	Indice dei contenuti	Richiesta una connessione Internet, I risultati non garantiti
•	Japanese	Table of Contents	Internet connection required, results not guaranteed
(0)	Korean	Table of Contents	Internet connection required, results not guaranteed
	Nederlands	<u>Inhoudsopgave</u>	Internetverbinding nodig, resultaten niet gegarandeerd
#	Norske	<u>Innholdsfortegnelse</u>	Internett-tilkobling kreves, resultater Ikke Garantert
	Russian	Table of Contents	Internet connection required, results not guaranteed
-	Suomalainen	<u>Sisallysluettelo</u>	Vaatii Internet-yhteyden, tulokset ole taattu
	Svenska	<u>Inneholl</u>	Internetanslutning kravs, resultat garanteras inte

## **Table of Contents**

- Introduction
  - Copyright

Language Support



- Table of Contents
- About this Document
  - Customize this Document
- How to Get Help
  - Before Contacting Support
- Defender
  - Quick Reference Guide
  - Operator's Manual
- Pro 5
  - Operator's Manual
- Greensea Software
  - Greensea Software Manual
  - Greensea KnowledgeBase
- Supplemental Manuals
  - Creating and Using Charts
- <u>Diagnostic Interfaces</u>
  - Blueprint Oculus Sonar
  - Blueprint Seatrac USBL
  - Nortek DVL
  - Video

## **About this Document**

### **Document Navigation**

You can navigate through the documentation to specific topics using the menu, or step through sequentially using the Next and Previous arrowhead buttons. The Next button will step you from the current topic to the next topic at the same level unless the current topic has a sub-topic. If the current topic has a sub-topic, the Next button will step you into the first sub-topic. The Previous button works similarly, but in reverse sequence. Your current location within the document is shown as a "breadcrumb" trail at the top of each page under the document title. You can click on any level of the breadcrumb hierarchy to go that location. You can also use the following keyboard shortcuts:

ACTION	KEYSTROKE or BUTTON
Previous Page	Alt-p or
Next Page	Alt-n or
Up one level of the breadcrumb hierarchy	Alt-u

Links are shown in brown font.

## **Finding Information**

This document includes a <u>Table of Contents</u>, <u>Glossary / Index</u> and Google search on each page. You must be connected to the Internet in order to be able to use the Google search, and you can select whether to search VideoRay's online document library only (the default) or the Internet.

## **Document Conventions**

Several symbols are used throughout this documentation to add emphasis and to assist in relocating important information. The following table describes these symbols and their uses.

SYMBOL	DESCRIPTION
DANGER	The <b>Danger</b> icon is used to indicate there is a potential risk of personal injury or death. Extra care should be taken to understand the risks, and all personnel should exercise caution. It may also be appropriate to warn others in the immediate vicinity.
CAUTION	The <b>Caution</b> icon is used to indicate there is a potential risk of damage to the equipment or surrounding property. Personnel should receive training in the appropriate procedures before attempting to operate or maintain the equipment.
0	The <b>Do Not</b> icon is used to indicate that an action or activity should NOT be performed.
<u>^</u>	The <b>Note</b> icon is used to highlight a specific detail or point of information.
Ÿ	The <b>Tip</b> icon is used to highlight a suggestion or recommendation.
	The <b>Manual Cross Reference</b> icon is used to link to reference material elsewhere in this document or in an external resource. To view the reference, click on the <b>Manual Cross Reference</b> icon.
•	The <b>Play Video</b> icon is used to link to a video about the topic. To view the video, click on the <b>Play Video</b> icon.
w	The <b>Highlight</b> icon is used to indicate that a section of text can be highlighted. Clicking on the icon will reload the page with the text highlighted. This may be useful for printing a page with highlights or to send someone a link to a page with specific text highlighted when they open the page. Try it here - click on this highlight icon.
€	The <b>Hand</b> icon is used to indicate an interactive element of the page. When you hover your mouse over the <b>Hand</b> icon, an image on the page will change to reflect the information in the text immediately prior to the hand icon. Try it here - hover your mouse over the following text and <b>Hand</b> icon to turn the <b>Hand</b> icon to the left blue: Interactive Text .

## **Document Customization - My\_Notes**

This document has been developed to allow local online versions to be customized using the My\_Notes feature. Users can add their own notes to each page. See the <u>Customizing this</u> <u>Document</u> page for more information about how to customize this document.

## **Beyond this Document**

There is no substitute for experience and/or training, especially with respect to the real purpose for which you plan to use this equipment. We encourage you to explore options beyond the scope of these materials to expand your knowledge and skills necessary to support your applications. In addition to this documentation, VideoRay offers training and technical support and hosts a general user discussion forum and user image gallery.

We also realize that collectively, users of our products spend considerably more time operating our systems than we do ourselves. Users also encounter more diverse operating environments across an extremely broad range of applications. We highly value this vast experience base, and invite and encourage you to share your experiences and suggestions with us. Please feel free to contact us by any of the methods listed below.

## **Quality Commitment**

VideoRay strives to design, manufacture, deliver and support the highest quality products and services, including this documentation. We have made every effort to ensure that this documentation is accurate and provides you with the most up-to-date information.

If you find any errors in this documentation or have suggestions for improvements, each page contains a "Help us improve this document" feedback link in the left margin (you must be connected to the Internet to use this link).

#### **Address**

212 East High Street Pottstown, PA 19464 **USA** 

#### **Email**

info@videoray.com General Information and Sales support@videoray.com Technical Support

## **Telephone**

+1 610-458-3000 Office +1 610-458-3010 Fax

### Disclaimer

This document is deemed accurate at the time of its writing, however it is not a legal contract and the information contained herein should not be construed to represent any form of commitment. This document as well as the associated products and services are subject to change without notice.

#### **Alternate Formats**

## Single HTML Page Format

This document is available as a single HTML page that can be viewed and/or printed by the viewer.

## **Portable / Printable Format**

An abbreviated print version of this document is also available in HTML and PDF formats in Letter and A4 sizes for viewing and/or printing. A free PDF Reader is available from Adobe. Printed versions of this document are available from VideoRay.

#### **HTML File Set**

This document set is also available for download as a self extracting zip archive for installation on your local device.

## **Customize this Documentation - My\_Notes**

My Notes are easy to incorporate directly into the pages of this manual. They can be used to clarify content, add additional information, or document your custom settings, operational tactics or procedures. My Notes are page specific and display at the bottom of the desired page under the "My Notes" heading. No programming is required - it is as simple as saving a file with your notes.

## **Creating My\_Notes**

My Notes can be written in HTML or plain text. HTML allows for more flexible formatting and inclusion of images or links to other web pages.

To add a My Note, create an HTML or text file containing the note and save it in the VideoRay\My Notes\ folder, which can be found in the computer account user's documents folder (Documents) for Windows 7, or My Documents) for Windows XP).

The file should be named the same as the page in which you want the note to appear, with a "my\_" prefix (without the quotes). For example, if you want a My Note to appear at the bottom of this page, the name of the file to create is: my custom my notes.html. The name of the page being viewed can be found in the address bar of the browser being used to display this documentation.

Liven if you are using a text file, the file name must end with the ".html" extension.

All My Notes files are processed as HTML, so if you are using a plain text file, you will need to add "" (without the quotes) at the beginning of the file and "" (without the quotes) at the end of the file if you want to preserve the layout. The "" and "" will not show up in the display.

Mhen using HTML, the My Notes folder serves as the root for relative links. An images folder is included for you to store images. You may add other folders or files as desired.

## Viewing My\_Notes

When you reload the page, your My\_Note will appear - there is nothing else to install or configure. A sample My\_Note file has been included to display the My\_Note below. You can use this file as a model for creating your own My\_Notes.

## **Updating My\_Notes**

To update a My\_Note, simply edit and re-save the My\_Note file.

## Removing My\_Notes

My Notes can be removed by deleting or renaming the My Note file.

## Sizing My\_Notes Display (Optional)

The default vertical size for My\_Notes is set to 200 pixels, which is used for the sample My\_Note below. Due to browser limitations, My-Notes do not size dynamically. This means that a long My\_Note may display a scroll bar in order to view the whole My-Note. You can adjust the size to eliminate the need for the scroll bar. To set the size of a My\_Note, you need to edit the file named "my\_notes\_size\_table.js" in the My\_Notes\ folder (location defined above). The file contains one line for each page of this document using the following format:

window.page\_name = size\_in\_pixels;

Find the line for the page that includes the My\_Note you want to resize and replace the value of <code>size\_in\_pixels</code> with the desired size in pixels. The page names are listed alphabetically. Example line from the "my\_notes\_size\_table.js" file for this page:

window.custom my notes = 200;

Note that ".html" in not included in the page name, and the line must end with a ";" Also, the optimum size required is dependent upon the size and aspect ratio of the browser window.



## How to Get Help

Help for your Mission Specialist is available through several channels.

### All Hours Self-Service / Crowd-Source Tools

Operator's Manuals and Standard Operating	www.videoray.com/support/manuals.html
Procedures	
Software Downloads	www.videoray.com/support/downloads.html
Frequently Asked Questions	www.rovfaq.com
ROV User Forum	www.rovinfo.com

## **Global Support**

Email	support@videoray.com
Phone	+1 610-458-3000 (select option 1)
Skype	videoray.support ( <i>by appointment</i> )
Remote Sessions	www.videoray.com/support/remote-support.html (by appointment)

## **Regional Support**

VideoRay Authorized Dealers and Service Centers www.videoray.com/dealer.html

## **Training**

Operator Training	www.videoray.com/learn-more/training.html
Advanced Maintenance	http://www.videoray.com/learn-more/training/advanced-maintenance-
Training	training.html

## **Operational Strategies and Tactics Support**

If you need help understanding how to apply your system to a specific project, contact VideoRay or you local VideoRay dealer. We can provide guidance or help you find a certified consultant.

## **Before Contacting Support**

Please make sure to consider the following information before contacting VideoRay's Technical Support to report a problem. The following information should available:

- User name and contact information
- · Name of the owner if not the same as the user
- System model
- Serial Number of the affected component(s)
- · Accessories in use
- Detailed information about the issue:
  - Symptoms
  - Operating conditions that create the symptoms
  - Anything new or unusually about the system or operations

In addition, please review VideoRay's Support website for additional information about:

- Principles of Customer Interactions
- · Customer Care Philosophy
- Technical Support Policy
- · Accessory Support Statement



# **Defender Manuals**

- Defender Quick Reference GuideDefender Operator's Manual



# **Pro 5 Manuals**

• <u>Defender Operator's Manual</u>



# **Greensea Software**

Greensea offers two reference documents:

- Operator's Manual
- Greensea KnowledgeBase (Internet connection required)



# **Supplemental Guides**



## **Diagnostic Interfaces**

- Blueprint Oculus Sonar
- Blueprint Seatrac USBL
- Nortek DVL
- Video

**CAUTION** Diagnostic interfaces also allow changes to the settings. Modifying the settings may result in unintended results including failure to operate.

Contact VideoRay for more information and support if you are interested in using these diagnostic interfaces.

## **Blueprint Oculus Sonar Settings**

The Blueprint Oculus Sonar settings can be modified by using the BluePrint ViewPoint software. However, ViewPoint is only available on Microsoft Windows, so a separate computer is required.

## Requirements

- · Windows Computer
- · Ethernet Cable

### **Procedures**

See the Oculus Sonar documentation for more information.

- 1. Connect the Ethernet cable from the Mission Specialist Operator Control Console to the Windows computer.
- 2. Change the IP address of the computer to 192.168.1.3.
- 3. Start the Mission Specialist system, but do not start the Greensea software.
- 4. Start the ViewPoint software on the Windows computer.
- 5. Click on the Connect button in the ViewPoint software.
- 6. Click on the wrench icon to access the settings.

**CAUTION** Diagnostic interfaces also allow changes to the device's settings. Modifying the settings may result in unintended results including failure to operate.

## **Blueprint Seatrac USBL Settings**

The Blueprint Seatrac USBL settings can be modified by using the BluePrint Seatrac software. However, Seatrac is only available on Microsoft Windows, so a separate computer is required.

## Requirements

· Windows Computer

### **Procedures**

See the Oculus Sonar documentation for more information.

- 1. Connect the deck cable from the Seatrac system to the Windows computer and the included power supply.
- 2. Start the Seatrac or Seatrac tools software on the Windows computer.

**CAUTION** Diagnostic interfaces also allow changes to the device's settings. Modifying the settings may result in unintended results including failure to operate.

## **Nortek DVL Settings**

The Nortek DVL settings can be accessed using a web browser.

The address for the Nortek DVL settings is 192.168.1.50.

**CAUTION** Diagnostic interfaces also allow changes to the device's settings. Modifying the settings may result in unintended results including failure to operate.

## **Video Settings**

The video settings can be accessed using a web browser.

The address for the primary video settings is <u>192.168.1.11</u>.

**CAUTION** Diagnostic interfaces also allow changes to the device's settings. Modifying the settings may result in unintended results including failure to operate.